

**CONAIRMAN™**



XPERT PRECISION™

**TOOL TIPS**

for the ultra-gentle expert nose & ear trimmer  
with diamond capture blades for precision results.

VSM50MA

# HERE YOU ARE.

**RIGHT WHERE YOU NEED TO BE, MAN.**

---

FROM THE STREETS OF  
BROOKLYN, NEW YORK

**WE ARE CHANGE  
MAKERS & STYLE CREATORS.**

WE'VE FOUGHT OUR WAY INTO  
YOUR HANDS TO HELP YOU CRAFT  
**A REPUTATION, NOT JUST ENGAGE  
IN SOME BRILLIANT GROOMING.**

---

KNOW YOUR WORTH, INVEST IN IT MAN & CHECK OUT OUR INSIDER  
KNOWLEDGE, TIPS & TRICKS TO MAKE THE MOST OF THE STYLE PATH  
YOUR FEET ARE FIRMLY PLANTED ON. GIDDY UP, IT'S GROOMING TIME.

---

CHECK OUT [CONAIRMAN.COM.AU](http://CONAIRMAN.COM.AU) FOR GROOMING TIPS  
& KNOW HOW TO LET YOU CRAFT A REPUTATION

---

**CONAIRMAN™**

**CRAFT A  
REPUTATION,  
MY MAN**

# IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following:

Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

**DANGER:** When the unit is used in a bathroom, remove the batteries after use since the proximity of water presents a hazard even when the appliance is switched off.



**WARNING:** Do not use or leave the trimmer in a position where it can become wet or there is a danger of it falling into a basin or other vessels containing water. Keep the appliance dry, unless it otherwise specified. Do not use this appliance in or near bathtubs, showers, basins or other vessels containing water.

- Do not immerse appliance in water or other liquids.
- Do not reach for an appliance that has fallen into water.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

**IMPORTANT:** Always ensure the appliance is switched off when not in use or before cleaning. Do not leave unattended when switched on. Do not place on any heat sensitive surface.

- Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
- Use this appliance only for its intended use as described within this instruction booklet.
- This appliance is not intended for commercial use.
- Never drop or insert any object into an opening.
- Do not place on any surface while it is operating.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use the appliance if it is damaged. In the event of damage, discontinue use immediately and contact your dealer for instructions on returning it for examination or exchange.

# THE XPERT PRECISION

BUCKLE UP, IT'S TRIMMING TIME.

The XPERT Precision is the expert ultra-gentle nose & ear trimmer with diamond capture blades for precision results.



1. Diamond-protect technology
2. Three-bevel blade system
3. Removable attachment head with blades are washable for easy cleaning
4. Oil free blades

5. Durable semi-metal housing with slim, compact design
6. Removable hygienic cap
7. 1x AA battery included
8. Battery compartment cover & ON/OFF switch

# PREPPING YOUR NEW TOOL

## INSERTING THE BATTERY

- To insert the AA battery, first ensure that the trimmer is switched off, then remove the battery compartment cover on the base by rotating the bottom of the trimmer to the left & the pull downwards (Fig.1).
- Insert the AA battery, positive terminal facing towards the open end.
- Replace the battery cover & twist to secure to the "0" position.
- Switch the trimmer on by turning the bottom part of the trimmer towards the right (Fig.2).
- If the finishing trimmer remains unused for a while or if the battery has run down, remove from the trimmer. This will increase the life of the trimmer.
- Replace battery with a new Alkaline or Lithium type battery.
- Check the battery contacts are clean in the timmer before replacing batteries.
- Ensure the battery is installed correctly with regard to polarity (+ and -).
- Exhausted batteries are to be removed from the appliance & safely disposed of.
- When the battery has run down, it should be disposed of at a recycling centre to safeguard the environment.
- Store unused batteries in their original packaging, away from metal objects that could short-circuit them. Never short-circuit batteries.

Fig.1





Fig.2



## BEFORE USING

- Always inspect the trimming head for noticeable signs of damage.
- Always inspect the trimming head before use to ensure the blades are free from hair, debris etc.
- Ensure the battery is correctly inserted & that the polarity (+ and -) is correct before use.


## REMOVING THE ATTACHMENT HEAD

- Before removing the trimming blade, always ensure the trimmer is switched off.
- To remove the trimming blade, turn it to the right so that the "I" mark on the attachment head aligns with the "arrow" mark on the body, then pull upwards (Fig.3).
- To re-attach the trimming blade, align the "arrow" mark on the body with the "I" mark on the attachment head, then turn to the left until the "I" mark aligns with the "o" mark on the body (Fig.4).

Fig.3



Fig.4



# TRIMMING TIPS

CHECK OUT **CONAIRMAN.COM.AU** FOR GROOMING TIPS & KNOW HOW TO LET YOU CRAFT A REPUTATION

1. Switch the trimmer on by twisting the On/Off switch on the bottom of the handle to the right, so that the "I" aligns with the small "I".
2. Gently insert the trimming head into the nose or ear & move the trimmer in a circular motion & slightly back & forth.
3. For best results, the trimmer on BEFORE you insert into your nostril or ear canal.
4. Never insert the trimmer more than 5-6mm into your nose or ears.
5. Never turn the trimmer off whilst in the nose & ears.

# TRIMMER CLEANING & MAINTENANCE

Because the trimmer blades are precision made for a very special use, they should always be handled with care. To ensure long-lasting performance of your trimmer, it is important to clean the blades after every use.


The blades are washable for easy cleaning. To remove the trimming blades for cleaning follow the instructions at REMOVING THE ATTACHMENT HEAD.

1. Ensure the trimmer is turned off.
2. After removing the trimming blade, take a small brush & brush away any loose hairs that have collected in the blades.
3. Rinse the trimming blades under running water (Fig.5 & Fig.6).
4. For proper functioning of the trimmer, the handle cannot touch or be immersed in water.
5. After cleaning, make sure to shake off excess water & dry the blades of the trimmer before replacing onto the handle.
6. To re-attach the trimming blade, follow the instructions at **REMOVING THE ATTACHMENT HEAD**.
7. To clean the handle of your trimmer, simple wipe with a cloth that has been dampened in water & mild detergent.

Fig.5



Fig.6



---

**NOTE: DO NOT ATTEMPT TO REPAIR OR REPLACE THE BLADES. IN THE EVENT THAT THE BLADES BECOME BLUNT OR DAMAGED, CONTACT THE CONAIR CUSTOMER CARE LINE (CONAIR CUSTOMER SERVICE).**

---

# WARRANTIES

- In this warranty document ("Warranty Document"), "Conair", "we" or "us" means:
  - Conair Australia Pty Limited (ABN 64 068 492 044) of The Equinox Centre, Suite 101, 18 Rodborough Rd, Frenchs Forest, NSW, 2086, in relation to products purchased in Australia; or Conair New Zealand Ltd of Conair New Zealand Limited, PO BOX 251159 Pakuranga, Auckland 2140, New Zealand in relation to products purchased in New Zealand.
  - Nothing in this Warranty Document limits or reduces (or purports to limit or reduce) any statutory guarantees pursuant to the Australian Consumer Law for Australian customers or the Consumer Guarantees Act 1993 for New Zealand customers.
  - If you have any questions about the product you have purchased in either Australia or New Zealand, please contact us on 1800 650 263 (for Australian customers) or 0800 266 247 (for New Zealand customers). Further contact details are set out at the bottom of this Warranty Document.

## STANDARD 2 YEAR (24 MONTH) WARRANTY

- AUSTRALIA:** Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.  
**NEW ZEALAND:** Our goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.
- Conair's name, postage address, email and phone number are available at the bottom of this Warranty Document, under "Contact Information".
- This Standard 2 Year (24 Month) Warranty ("Standard Warranty") applies for a period of 2 years (24 months) from the date that you purchased your product ("Standard Warranty Period"). For clarity, the relevant defect must appear within the Standard Warranty Period timeframe for this Standard Warranty to apply.
- If your product is defective, and the product is covered under this Standard Warranty, you should, in the first instance, take the product back to the place you purchased it from or

contact us directly if you are unable to take the product back to the place of purchase. The procedure for claiming under this Standard Warranty is as detailed below.

6. To make a Standard Warranty claim, you will need to return the defective product back to the place it was purchased where it will be assessed under this Standard Warranty. Or if you are unable to return the defective product back to the place of purchase, you will need to call our Customer Service team on 1800 650 263 (for Australian Customers) or 0800 266 247 (for New Zealand customers) or send an email to the email address provided below under 'Contact Information'.
7. **In order to make a claim under this Standard Warranty, you will need to provide the following details to Conair:**
  1. **Date of purchase**
  2. **Retailer name & location**
  3. **Product model number & name**
  4. **Confirm you have your purchase receipt**
  5. **Detail the problem with your product.**
8. If you make a Standard Warranty claim directly with us, we will ask for you to send us back the defective product along with the purchase receipt. To do this, please head to your local post office and send the product to our reply paid address which is: Reply Paid 146, PO Box 146, Terrey Hills NSW 2084. For clarity, we will be responsible for covering the cost of postage to the above reply paid address.
9. Once we receive your product, we assess it accordingly. Upon analysing the defect, we will either: a) have the product replaced and sent back to you; or b) refund you (either in part or in full).
10. The benefits provided to you under this Standard Warranty are in addition to other rights and remedies available to you under consumer law.
11. Within the Standard Warranty Period, if your product suffers a defect in the materials or workmanship, Conair will either refund or replace your product, in our sole discretion, for no charge.
12. Under this Standard Warranty, we do not have to refund, repair or replace your product if the product's defect or damage is a result of misuse, abuse, accident, act of God such as lightning, or nonobservance of Conair's instruction booklet on the part of the user.
13. The Standard Warranty does not cover ordinary wear and tear of the product.
14. This Standard Warranty is immediately void if: a) any serial number or product plate is removed or defaced, or b) the product has been serviced or otherwise repaired by a person

not authorised to do so by Conair or where non-approved replacement parts are used.

15. You are aware that the product is designed for domestic use only and that it must be connected to the electrical voltage supply as specified in the ratings label located on the product itself and detailed in the product's instruction booklet. The Standard Warranty does not cover defects arising from non-domestic use or use of incorrect voltage supply.
16. This Standard Warranty may only be claimed where proof of original purchase is presented, for example, original receipt or invoice.
17. The Standard Warranty on any replacement product or parts will expire on the same date that the Standard Warranty Period on the original product expires, as far as the law permits.
18. In order to obtain a remedy under this Standard Warranty, the defect must have occurred during this Standard Warranty Period and you (as the purchaser) bear the onus of proving that fact, and that the defect was not caused by any of the exclusions above.
19. This Standard Warranty does not cover any product purchased from any entity who is not an authorised Conair distributor or reseller. For clarity, all warranties are only enforceable in Australia and New Zealand.
20. To the fullest extent permitted by law, Conair does not accept liability for: a) any loss or damage however suffered, caused by or arising out of any failure to use a product in accordance with Conair's instruction booklet; and b) any indirect, consequential or economic loss or damage however caused.
21. We will be responsible for all postage and freight charges and any other expenses incidental to claiming under the Standard Warranty, however you must send the product back to our Reply Paid address (which is: Reply Paid 146, PO Box 146, Terrey Hills NSW 2084).
22. If your product is defective, and the product is covered by this Standard Warranty, you should take the product back to the place you purchased it from or contact us directly using the contact information provided in the Contact Information section below.
23. To honour the Standard Warranty, you must retain your proof of original purchase, for example, original receipt or invoice and you must present the proof of original to obtain replacement, refund or service under this Standard Warranty, alongside your defective product.
24. You understand that the Standard Warranty may only be claimed where proof of original purchase is presented, i.e. original purchase receipt or invoice. When asked to do so, please provide your proof of original purchase along with the requested information/defective item.

## **SPARE PARTS**

25. Replacement parts may be available for your product. Contact us on the phone or email address provided for more details. Please provide your product name/model number details, date of purchase and part you require.

## **CONTACT INFORMATION**

### **Conair Australia Pty Ltd**

PO Box 146 Terrey Hills NSW 2084

Customer Service

Australia

1800 650 263

email: [aus\\_info@conair.com](mailto:aus_info@conair.com)

### **Conair New Zealand Ltd**

PO Box 251159 Pakuranga, Auckland New Zealand 2140

Customer Service

New Zealand

0800 266 247

email: [aus\\_info@conair.com](mailto:aus_info@conair.com)



©2023 Conair Australia Pty. Ltd.  
Suite 101, 18 Rodborough Rd  
Frenchs Forest NSW 2086  
Australia

Conair New Zealand Limited  
PO BOX 251159  
Pakuranga, Auckland 2140  
New Zealand

## CONTACT US

For advice & tips on your new ConairMan product email us on:  
[aus\\_info@conair.com](mailto:aus_info@conair.com)

## CUSTOMER SERVICE

Australia: 1800 650 263  
New Zealand: 0800 266 247

Check out [CONAIRMAN.COM.AU](http://CONAIRMAN.COM.AU) for grooming tips & know how to let you craft a reputation.

**CONAIRMAN™**

**CRAFT A  
REPUTATION,  
MY MAN**

IB-22/372A