

**CONAIRMAN**



THE XPERT HEAD SHAVE™

# TOOL TIPS

Rechargeable rotary head shaver with 3D floating heads for the closest shave plus nose trimmer and skin brush attachments.

CMH902A

# HERE YOU ARE.

**RIGHT WHERE YOU NEED TO BE, MAN.**

---

FROM THE STREETS OF  
BROOKLYN, NEW YORK

**WE ARE CHANGE  
MAKERS & STYLE CREATORS.**

WE'VE FOUGHT OUR WAY INTO  
YOUR HANDS TO HELP YOU CRAFT

**A REPUTATION, NOT JUST ENGAGE  
IN SOME BRILLIANT GROOMING.**

---

KNOW YOUR WORTH, INVEST IN IT MAN & CHECK OUT OUR INSIDER  
KNOWLEDGE, TIPS & TRICKS TO MAKE THE MOST OF THE STYLE PATH  
YOUR FEET ARE FIRMLY PLANTED ON. GIDDY UP, IT'S GROOMING TIME.

---

CHECK OUT [CONAIRMAN.COM.AU](http://CONAIRMAN.COM.AU) FOR GROOMING TIPS  
& KNOW HOW TO LET YOU CRAFT A REPUTATION

---

**CONAIRMAN™**

**CRAFT A  
REPUTATION,  
MY MAN**

# IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following:

Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

**DANGER:** When the unit is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.



**WARNING:** Do not use or leave the USB charging cable in a position where it can become wet or there is a danger of it falling into a basin or other vessels containing water. This appliance is suitable for use in a bath or shower. The parts that have to be fixed must be installed so they cannot fall into water. Detach the hand-held part from the USB charging cable before cleaning in water.

- Do not immerse appliance in water or other liquids.
- Do not reach for an appliance that has fallen into water.
- Take care to avoid contact between the moving blades of the unit and the skin, paying particular attention to the face, neck and hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This class III handheld appliance must only be charged at Separated Extra low voltage, by using a 5VDC 1A ( Maximum power less than 15W) power supply (power supply is not provided in the package)
- This appliance contains rechargeable batteries that are non- replaceable.


**IMPORTANT:** Always unplug the appliance when not in use or before cleaning. Do not leave unattended when switched on. Do not place on any heat sensitive surface.

- Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
- Use this appliance only for its intended use as described within this instruction booklet.
- Always unplug the appliance when fully charged.
- This appliance is not intended for commercial use.
- Never drop or insert any object into an opening.
- Do not use the appliance with damaged or broken attachment combs or with any teeth missing from the blades, as injury may occur.
- Do not place on any surface while it is operating.
- Keep the USB cord away from heated surfaces
- Never twist or pull on the USB cord.
- Do not use an extension USB cord with this appliance.
- After use do not wrap the USB cord around the appliance as in time this may cause the cord to fracture. Coil cord loosely by the side of the appliance in storage.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use the appliance if it is damaged. In the event of damage, discontinue use immediately and contact your dealer for instructions on returning it for examination or exchange. If the USB cord is damaged, it must be replaced to avoid a hazard.
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- When using with the USB charging adaptor, for additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical current circuit supplying the bathroom. Ask your installer for advice.
- The appliance is only to be used with the USB charging cord provided with the appliance.


# THE XPERT HEAD SHAVE

BUCKLE UP, IT'S SHAVING TIME.

The XPERT Head Shave is the rechargeable rotary shaver with 3D floating heads for the closest shave.



- |   |                             |
|---|-----------------------------|
| 1. Rotary shaver head                             | 6. Cleaning brush           |
| 2. ON/OFF button                                  | 7. Type-C USB charging cord |
| 3. LED display                                    | 8. Protection cap           |
| 4. Guide combs for precision shaver (1.5/3/6/9mm) | 9. Precision trimmer        |
| 5. Oil  | 10. Nose trimmer            |
|   | 11. Skin brush              |



# HOW TO USE

## CHARGING

The XPERT Head Shave is so easy to use. But before you start using your new tool, you must take the time to charge it for **3 HOURS BEFORE ITS FIRST USE**. Your new tool comes with a small amount of charge, but the initial charge will ensure your new tool will have optimum power performance to give you smooth fast cutting, every time.

- Before using the shaver for the first time, charge continuously for 3 hours.
- Maximum battery capacity will be reached only after 3 charging and discharging cycles.
- To charge the shaver, first make sure it is switched off. Open the USBC port cover and insert the type C USB plug into the bottom of the shaver, then insert the USB cable into a USBA wall adaptor with output 5.0V DC, 1000mA. Plug the adaptor into any wall outlet at the voltage listed on the label affixed to the adaptor.
- The adaptor may become warm while charging. This is normal.
- The USB cable can alternatively be plugged directly into a USB port for charging.
- When charging, the unit will not operate.
- To maintain optimum capacity of the rechargeable battery, it is highly recommended to fully discharge and then recharge the shaver for 3 hours every 6 months.
- A full charge time of 3 hours will provide 90 minutes of cordless running time.
- Once the appliance is fully charged, the battery symbol will show 4 full bars. Unplug the adaptor from the outlet, then the USB cable from the appliance and prepare for use.

**WARNING:** If the charging light suddenly starts to flash rapidly, the appliance is faulty. If this happens, stop charging, remove the adaptor from the outlet and contact our Customer Care Center for further advice (see the Warranty section of this information booklet).

## LED DISPLAY



The LED display features the following:

### REMAINING RUN TIME



When turned on, and running or charging, the LED number indicates the remaining runtime in minutes.

**NOTE:** run time is an estimate and impacted by battery charge level & operating temperatures.



### BATTERY CHARGE INDICATOR

Illuminates to show the shaver battery level and charging status.



### TRAVEL LOCK

1. To prevent the tool from switching on unintentionally, you can press and hold down the ON/OFF button for 3 seconds until the lock icon flashes 3 times and disappears. If you try and turn on the unit while in travel lock the lock icon will flash 3 times indicating travel lock is activated.
2. To unlock and turn your shaver on again, press and hold the ON/OFF button for 3 seconds. Once the remaining run time is shown and the unit starts operating, release the button. The shaver is now unlocked and will work as normal when switched off and back on.

## BEFORE USING

- Always inspect the rotary heads and blades for noticeable signs of damage and to ensure they are free from hair, debris etc.
- Always inspect the rotary heads & blades before use to ensure they are free from hair, debris etc.
- If the foil is cracked, broken or loose, do not use it again & replace with a new foil. Using a foil in a faulty condition can cause injury.
- Ensure the shaver is sufficiently charged before use.
- Do not shave on open wounds, cuts, burns, warts, moles or on sunburned skin.
- Do not use the foil shaver if you suffer from skin irritations or infections, such as psoriasis or eczema. If at all unsure always consult your doctor before use.

**IMPORTANT:** The XPERT Head Shave will stop working if the unit is filled with hair or debris to protect from damage. Ensure you clean the shaver regularly to maintain full functionality. If the blades have been cleaned and the unit still isn't operating correctly please contact customer service.

## SHAVING YOUR HEAD

The XPERT Head Shave is designed to maintain a smooth shaved scalp to achieve a precise clean look. It is important if hair is longer than 2mm that it is removed using a clipper or trimmer before using the XPERT Head Shave shaver head. The XPERT Head Shave comes with a trimmer head that can be used without a comb guide for the perfect pre-shave preparation. Before using make sure that the scalp is clean & free from oil & dirt.

Having a warm shower before use will also help to soften the scalp stubble. Please note that if the hair is too long the trimmer might not work and jam or pull the hair.


1. Remove the protective cover.
2. Switch the trimmer on by pressing down on the on/off button (hold for 3 seconds if the travel lock has been engaged).
3. Hold the shaver heads parallel to the skin & use short overlapping circular motions both clock wise & anti-clockwise.

- The flexing heads and floating blades will contour to the shape of your scalp. You don't have to push the shaver on the skin too hard as it could cause irritation, slow down the rotating blades and prevent a perfect shave. Simply exert light pressure & let the shaver heads do all the work.

**IMPORTANT:** For best results for maintenance it is recommended to every 3 to 4 days (or even daily). Do not use the shaver on hair growth longer than 4 days or 2mm as this will damage the blades and foils. It is not recommended to use the shaver on the face.

## USING THE TRIMMER ATTACHEMENT

The trimmer attachment can be used to pre-cut hair that is longer than 2mm before shaving. This trimmer is also ideal for trimming and shaping sideburns, beards and mustaches. To help complete your facial hair grooming routine, there are four guide combs for different cutting lengths 1.5/3/6/9mm.



To use the trimmer attachment.

- Ensure the unit is turned off and remove the shaver head by pulling straight out from the unit.
- Snap on the trimmer head attachment by aligning the fitting marks and pushing down until you feel it lock into place.
- For beard and stubble trimming, choose the desired cutting comb guide length and attach to the blade. It is recommended to use the longest guide first and work to way to shorter as desired.
- For the closest results on the face or neck, and preparing the scalp for when hair has gotten too long, do not attach and comb guide.

## USING THE SKIN CLEANSING BRUSH ATTACHEMENT

The skin cleansing brush scrubs away dirt, dead skin and oil to help deep clean pores and refresh skin.

To use the attachment.

- Ensure the unit is turned off and remove the shaver head by pulling straight out from the unit.
- Snap on the brush attachment by aligning the fitting marks and pushing down until you feel it lock into place.



## USING THE NOSE TRIMMER ATTACHEMENT

The trimmer quickly trims unwanted nose and ear hair without nicks or cuts.

To use the trimmer attachment.

1. Ensure the unit is turned off and remove the shaver head by pulling straight out from the unit.
2. Snap on the trimmer attachment by aligning the fitting marks and pushing down until you feel it lock into place.



## WET/DRY FEATURE

This device is IPX7 showerproof rated only when unplugged from a wall outlet.

Once it is unplugged, it can be safely used in the shower and cleaned using running water from a tap. It is important to ensure the USB charging port cover is securely closed. The unit is not meant to be submerged in water. Always allow the shaver to dry thoroughly after each use and before storing.

## TRIMMER CHARGING PRECAUTIONS

- Avoid charging the battery at temperatures below 5°C or above 35°C.
- Avoid charging the battery in direct sunlight or near a radiating heat source.

## CORDLESS OPERATION

- Charge the appliance. First, make sure it is switched off. Insert the type C USB plug into the bottom of the appliance, then the USB cable into a USB wall adaptor with output 5.0V DC, 1000mA. Plug the adaptor into any wall outlet at the voltage listed on the label affixed to the adaptor. The LED light will appear when the USB cable is correctly inserted into the appliance, the USB wall adaptor and the USB wall adaptor is connected to an outlet.
- Once the appliance is fully charged, the charging light will stop flashing, but remain on. Unplug the adaptor from the outlet, then the USB cable from the appliance and prepare for use.

**NOTE:** As an extra safety feature, this appliance is designed to not operate while charging.

# SHAVER CLEANING & MAINTENANCE

**Because the shaver rotary heads & blades are precision made & very sharp, always handle with care.**

To ensure the long-lasting performance of your shaver & to keep it clean & odour free, check & clean after every use, following the below instructions for cleaning the shaver head and foil blades.

After each use

1. Turn the shaver OFF. To open the 3 outer blade heads pull up from the centre (FIG.1) until all are open (FIG.2.) Then remove the centre blade head by lifting out (FIG.3)
2. Using the supplied brush clean any excess hair from the hair chamber & around the blades into a bin.
3. Clip the centre blade head back in. When aligned correctly the magnets will align and it will snap into place. Then close the outer blade heads until they snap secure.
4. For a more thorough cleaning the shaver heads can be run under the flow of tap water to remove any excess hair. Carefully shake off excess water and let the shaving head air-dry completely before closing.
5. Always store the shaver head with the protection cap placed over the foil blades to protect from debris and damage.



FIG.1



FIG.2



FIG.3

## TO CLEAN NOSE TRIMMER ATTACHMENT

1. Turn the shaver OFF. To remove the nose trimmer head by pulling straight out from the unit.
2. Turn the head counter-clockwise until the "I" mark aligns with the "Δ" mark, then lift the head gently (Fig. 1).
3. Using the supplied brush clean any excess hair, or rinse the head under water (Fig. 2). Carefully shake off excess water and let the shaving head air-dry completely before closing.
4. To reassemble the head onto the body, the shaft must be aligned with the hole (FIG.3), then align the "I" mark on the head with the "Δ" mark on the body and then turn clockwise until the "I" mark aligns with the "I" mark on the body (FIG.4) .




FIG.1





FIG.2

FIG.3

FIG.4

# WORLDWIDE VOLTAGE

This appliance has a multi voltage charging power supply feature for worldwide use. The voltage automatically converts for ease of use from 100v - 240v. This appliance has an automatic internal converter which will automatically convert the voltage without the need of a switch. A suitable USB wall adaptor will be required, please refer to the chart below.

USB Wall adaptor required	Voltage and plug adaptors	Country	Voltage setting
	British plug: 230V	Ireland, Great Britain, Singapore, South America, Hong Kong (parts only), Africa (parts only)	230V
	European plug: 230V	Asia, Europe, Middle East Noumea, Scandinavia, South America, Hong Kong (parts only)	230V
	Australian and New Zealand plug: 230-240V	Australia, New Zealand	230-240V
	American plugs: 120V	North America, Japan, Canada (parts of)	120V

# BATTERY DISPOSAL

This XPERT Head Shave contains a lithium battery. To protect the environment, the appliance must be disposed of safely at the end of its useful life.



Li-ion

Please take the appliance to a recycling centre, where the internal rechargeable battery should be removed by a professional and recycled separately.

For more information about the recycling of electrical and battery operated appliances, please contact your local council office or your household waste disposal service.

# WARRANTIES

1. In this warranty document ("Warranty Document"), "Conair", "we" or "us" means:

- Conair Australia Pty Limited (ABN 64 068 492 044) of The Equinox Centre, Suite 101, 18 Rodborough Rd, Frenchs Forest, NSW, 2086, in relation to products purchased in Australia; or Conair New Zealand Ltd of Conair New Zealand Limited, PO BOX 251159 Pakuranga, Auckland 2140, New Zealand in relation to products purchased in New Zealand.
- Nothing in this Warranty Document limits or reduces (or purports to limit or reduce) any statutory guarantees pursuant to the Australian Consumer Law for Australian customers or the Consumer Guarantees Act 1993 for New Zealand customers.
- If you have any questions about the product you have purchased in either Australia or New Zealand, please contact us on 1800 650 263 (for Australian customers) or 0800 266 247 (for New Zealand customers). Further contact details are set out at the bottom of this Warranty Document.

## STANDARD 2 YEAR (24 MONTH) WARRANTY

2. **AUSTRALIA:** Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled

to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**NEW ZEALAND:** Our goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.

3. Conair's name, postage address, email and phone number are available at the bottom of this Warranty Document, under "Contact Information".
4. This Standard 2 Year (24 Month) Warranty ("Standard Warranty") applies for a period of 2 years (24 months) from the date that you purchased your product ("Standard Warranty Period"). For clarity, the relevant defect must appear within the Standard Warranty Period timeframe for this Standard Warranty to apply.
5. If your product is defective, and the product is covered under this Standard Warranty, you should, in the first instance, take the product back to the place you purchased it from or contact us directly if you are unable to take the product back to the place of purchase. The procedure for claiming under this Standard Warranty is as detailed below.
6. To make a Standard Warranty claim, you will need to return the defective product back to the place it was purchased where it will be assessed under this Standard Warranty. Or if you are unable to return the defective product back to the place of purchase, you will need to call our Customer Service team on 1800 650 263 (for Australian Customers) or 0800 266 247 (for New Zealand customers) or send an email to the email address provided below under 'Contact Information'.
7. **In order to make a claim under this Standard Warranty, you will need to provide the following details to Conair:**
  1. **Date of purchase**
  2. **Retailer name & location**
  3. **Product model number & name**
  4. **Confirm you have your purchase receipt**
  5. **Detail the problem with your product.**
8. If you make a Standard Warranty claim directly with us, we will ask for you to send us back the defective product along with the purchase receipt. To do this, please head to your local post office and send to the product to our reply paid address which is: Reply Paid 146, PO Box 146, Terrey Hills NSW 2084. For clarity, we will be responsible for covering the cost of postage to the above reply paid address.
9. Once we receive your product, we assess it accordingly. Upon analysing the defect, we will either: a) have the product replaced and sent back to you; or b) refund you (either in part or

in full).

10. The benefits provided to you under this Standard Warranty are in addition to other rights and remedies available to you under consumer law.
  11. Within the Standard Warranty Period, if your product suffers a defect in the materials or workmanship, Conair will either refund or replace your product, in our sole discretion, for no charge.
  12. Under this Standard Warranty, we do not have to refund, repair or replace your product if the product's defect or damage is a result of misuse, abuse, accident, act of God such as lightning, or nonobservance of Conair's instruction booklet on the part of the user.
  13. The Standard Warranty does not cover ordinary wear and tear of the product.
  14. This Standard Warranty is immediately void if: a) any serial number or product plate is removed or defaced, or b) the product has been serviced or otherwise repaired by a person not authorised to do so by Conair or where non-approved replacement parts are used.
  15. You are aware that the product is designed for domestic use only and that it must be connected to the electrical voltage supply as specified in the ratings label located on the product itself and detailed in the product's instruction booklet. The Standard Warranty does not cover defects arising from non-domestic use or use of incorrect voltage supply.
  16. This Standard Warranty may only be claimed where proof of original purchase is presented, for example, original receipt or invoice.
  17. The Standard Warranty on any replacement product or parts will expire on the same date that the Standard Warranty Period on the original product expires, as far as the law permits.
  18. In order to obtain a remedy under this Standard Warranty, the defect must have occurred during this Standard Warranty Period and you (as the purchaser) bear the onus of proving that fact, and that the defect was not caused by any of the exclusions above.
  19. This Standard Warranty does not cover any product purchased from any entity who is not an authorised Conair distributor or reseller. For clarity, all warranties are only enforceable in Australia and New Zealand.
  20. To the fullest extent permitted by law, Conair does not accept liability for: a) any loss or damage however suffered, caused by or arising out of any failure to use a product in accordance with Conair's instruction booklet; and b) any indirect, consequential or economic loss or damage however caused.
  21. We will be responsible for all postage and freight charges and any other expenses incidental to claiming under the Standard Warranty, however you must send the product back to our Reply Paid address (which is: Reply Paid 146, PO Box 146, Terrey Hills NSW 2084).
-

22. If your product is defective, and the product is covered by this Standard Warranty, you should take the product back to the place you purchased it from or contact us directly using the contact information provided in the Contact Information section below.
23. To honour the Standard Warranty, you must retain your proof of original purchase, for example, original receipt or invoice and you must present the proof of original to obtain replacement, refund or service under this Standard Warranty, alongside your defective product.
24. You understand that the Standard Warranty may only be claimed where proof of original purchase is presented, i.e. original purchase receipt or invoice. When asked to do so, please provide your proof of original purchase along with the requested information/defective item.

### **SPARE PARTS**

25. Replacement parts may be available for your product. Contact us on the phone or email address provided for more details. Please provide your product name/model number details, date of purchase and part you require.

### **CONTACT INFORMATION**

#### **Conair Australia Pty Ltd**

PO Box 146 Terrey Hills NSW 2084

Customer Service

Australia

1800 650 263

email: [aus\\_info@conair.com](mailto:aus_info@conair.com)

#### **Conair New Zealand Ltd**

PO Box 251159 Pakuranga, Auckland New Zealand 2140

Customer Service

New Zealand

0800 266 247

email: [aus\\_info@conair.com](mailto:aus_info@conair.com)



©2026 Conair Australia Pty. Ltd.  
Suite 101, 18 Rodborough Rd  
Frenchs Forest NSW 2086  
Australia

Conair New Zealand Limited  
PO BOX 251159  
Pakuranga, Auckland 2140  
New Zealand

## CONTACT US

For advice & tips on your new ConairMan product email us on:  
[aus\\_info@conair.com](mailto:aus_info@conair.com)

## CUSTOMER SERVICE

Australia: 1800 650 263  
New Zealand: 0800 266 247

Check out [CONAIRMAN.COM.AU](http://CONAIRMAN.COM.AU) for grooming tips & know how to let you craft a reputation.

**CONAIRMAN™**

**CRAFT A  
REPUTATION,  
MY MAN**